


next
SLS
SLS112
STUDIO LIVE

USER MANUAL

www.laney.co.uk



British Engineering from the
Black Country United Kingdom



Dear Player,


Thank you very much for purchasing your new Laney product and becoming part of the worldwide Laney family. Each and every Laney unit is designed and built with the utmost attention to care and detail, so I trust yours will give you many years of enjoyment.

Laney products have a heritage which stretches back to 1967 when I first began building valve amplifiers in my parent's garage.

Since then we have moved on from strength to strength developing an extensive range of guitar, bass, public address, multi instrument and keyboard amplification products along with a list of Laney endorsees that includes some of the world's most famous and respected musicians.

At the same time we believe we have not lost sight of the reason Laney was founded in the first place - a dedication to building great sounding amplification for working musicians.

Warm Regards,

A stylized, handwritten signature in black ink, consisting of a large, sweeping 'L' followed by a series of loops and a final horizontal stroke.

Lyndon Laney
Chairman & Founder



NEXUS-SLS

Professional Hybrid Tube Bass Head



NEXUS-SLS112

Professional Hybrid Tube Bass Combo

Introduction

- Introducing the NEXUS-SLS Head and NEXUS-SLSI 12 Combo. Both compact and very portable, but don't be fooled by this - they certainly pack a punch!

NEXUS-SLS

- Hybrid Tube Bass Amplifier, "Loaded with a high voltage ECC83 tube for natural tube warmth and compression, along with a wide dynamic range, forming the source of the NEXUS-SLS tone".
- Up to 500 Watts of controllable sound dynamics from power amplifier and tube stage. With adjustable cabinet impedance match, a wide range of cabinets can be used without fear of overload.
- Ease of use with simple ergonomic fascia layout.
- Onboard (Laney designed) high quality digital bass effects for sound enhancement.
- USB-DAW connection facility with Re-Amp for all your recording requirements.
- Effects loop for outboard processor integration.
- Compressor; Tilt, Touch functions.
- Professional balanced DI facilities to connect to any PA desk.
- Headphone output for silent practice.
- Auxiliary input for backing tracks.
- Full protection against load errors or over temperature with fast auto re-set.
- Built-in automatic fan cooling in high ambient temperatures.
- Universal mains input for worldwide usage without the need to change anything except your power cord.
- Small, rugged, all steel, light weight.

NEXUS-SLSI 12

- All the great features above, including:
- Lightweight, but heavy duty plywood cabinet.
- "TUFF STUFF" finish - an extremely tough, ultra durable polyurethane coating. Built to deal with the rigours of life on the road.
- 12" lightweight Neodymium driver.
- 1" compression driver with switchable On/Off and Hi/Lo controls.
- Unique tilt mechanism to target the sound.
- Sturdy metal corner handles coupled with lightweight construction makes carrying the NEXUS-SLSI 12 a breeze!
- Convenient storage area at the rear for cables, pedals etc.

Important Safety Instructions

WARNING: When using electrical products, basic cautions should always be followed, including the following:

1. Read these instructions.
2. Keep these instructions safe.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. An apparatus with Class I construction shall be connected to a mains socket outlet with a protective connection. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point they exit from the apparatus.
11. Only use attachments/accessories provided by the manufacturer.
12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer; or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. The mains plug or appliance coupler is used as the disconnect device and shall remain readily operable. The user should allow easy access to any mains plug, mains coupler and mains switch used in conjunction with this unit thus making it readily operable. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Never break off the ground pin. Connect only to a power supply of the type marked on the unit adjacent to the power supply cord.
16. If this product is to be mounted in an equipment rack, rear support should be provided.
17. Note for UK only: If the colours of the wires in the mains lead of this unit do not correspond with the terminals in your plug, proceed as follows:
 - a) The wire that is coloured green and yellow must be connected to the terminal that is marked by the letter E, the earth symbol, coloured green or coloured green and yellow.
 - b) The wire that is coloured blue must be connected to the terminal that is marked with the letter N or the colour black.
 - c) The wire that is coloured brown must be connected to the terminal that is marked with the letter L or the colour red.
18. This electrical apparatus should not be exposed to dripping or splashing and care should be taken not to place objects containing liquids, such as vases, upon the apparatus.
19. Exposure to extremely high noise levels may cause a permanent hearing loss. Individuals vary considerably in susceptibility to noise-induced hearing loss, but nearly everyone will lose some hearing if exposed to sufficiently intense noise for a sufficient time.

The U.S. Government's Occupational Safety and Health Administration (OSHA) has specified the following permissible noise level exposures: According to OSHA, any exposure in excess of the above permissible limits could result in some hearing loss. Earplugs or protectors to the ear canals or over the ears must be worn when operating this amplification system in order to prevent a permanent hearing loss, if exposure is in excess of the limits as set forth above. To ensure against potentially dangerous exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of producing high sound pressure levels such as this amplification system be protected by hearing protectors while this unit is in operation.


Duration Per Day in Hours	Sound Level dBA, slow response
8	90
6	92
4	95
3	97
2	100
1 1/2	102
1	105
1/2	110
1/4 or less	115

	Intended to alert the user to the presence of uninsulated 'Dangerous Voltage' within the products enclosure that may be sufficient to constitute a risk of electrical shock to persons. Ce symbole est utilisé pur indiquer a l'utilisateur de ce produit de tension non-isolee dangereuse pouvant etre d'intensite suffisante pour constituer un risque de choc electrique. Este simbolo tiene el proposito de alertar al usuario de la presencia de '(voltaje) peligroso' que no tiene aislamiento dentro de la caja del producto que puede tener una magnitud suficiente como para constituir riesgo de corrientazo. Dieses Symbol soll den Anwender vor unisolierten gefährlichen Spannungen innerhalb des Gehäuses warnen, die von Ausreichender Stärke sind, um einen elektrischen Schlag verursachen zu können.
	Intended to alert the user of the presence of important operating and maintenance (Servicing) instructions in the literature accompanying the product. Dieses Symbol soll den Anwender vor unisolierten gefährlichen Spannungen innerhalb des Gehäuses warnen, die von Ausreichender Stärke sind, um einen elektrischen Schlag verursachen zu können. Este simbolo tiene el proposito de la alertar al usuario de la presencia de instrucccones importantes sobre la operacion y mantenimiento en la literatura que viene conel producto. Dieses Symbol soll den Benutzer auf wichtige Instruktionen in der Bedienungsanleitung aufmerksam machen, die Handhabung und Wartung des Produkts betreffen.
CAUTION: ATTENTION: PRECAUCION: VORSICHT:	Risk of electrical shock - DO NOT OPEN. To reduce the risk of electrical shock, do not remove the cover. No user serviceable parts inside. Refer servicing to qualified personnel. Risques de choc electrique - NE PAS OUVIRIR Afin de reduire le risque de choc electrique, ne pas enlever le couvercle. Il ne se trouve a l'interieur aucune piece pouvant etre reparee par l'utilisateur. Confier l'entretien a un personnel qualifie. Riesgo de corrientazo - no abra Para disminuir el riesgo de corrientazo, no abra la cubierta. No hay piezas adentro que el pueda reparar. Deje todo mantenimiento a los tecnicos calificados. Risiko - Elektrischer Schlag! Nicht offen! Um das Risiko eines elektrischen Schlages zu vermeiden, nicht die Abdeckung entfernen. Es befinden sich keine Teile darin, die vom Anwender repariert werden Können. Reparaturen nur von qualifiziertem Fachpersonal durchführen lassen.
WARNING: ADVERTISSEMENT: ADVERTENCIA: ACHTUNG:	To prevent electrical shock or fire hazard, do not expose this appliance to rain or moisture. Before using this appliance please read the operating instructions for further warnings. Afin de prevenir les risques de decharge electrique ou de feu, n'exposez pas cet appareil a la pluie ou a l'humidite. Avant d'utiliser cet appareil, lisez les advertissements supplementaires situes dans le guide. Para evitar corrientazos o peligro de incendio, no deja expuesto a la lluvia o humedad este aparato Antes de usar este aparato, lea mas advertencias en la guia de operacion. Um einen elektrischen Schlag oder Feuergefahr zu vermeiden, sollte dieses Gerät nicht dem Regen oder Feuchtigkeit ausgesetzt werden. Vor Inbetriebnahme unbedingt die Bedienungsanleitung lesen.

After unpacking your amplifier check that it is factory fitted with a three pin 'grounded' (or earthed) plug. Before plugging into the power supply ensure you are connecting to a grounded earth outlet.

If you should wish to change the factory fitted plug yourself, ensure that the wiring convention applicable to the country where the amplifier is to be used is strictly conformed to. As an example in the United Kingdom the cable colour code for connections are as follows.

EARTH or GROUND GREEN/YELLOW
NEUTRAL - BLUE
LIVE - BROWN



NOTE

This manual has been written for easy access of information. The front and rear panels are graphically illustrated, with each control and feature numbered. For a description of the function of each control feature, simply check the number with the explanations adjacent to each panel.

Your Laney amplifier has undergone a thorough two stage, pre-delivery inspection, involving actual play testing.

When you first receive your Laney guitar amplifier, follow these simple procedures:


(i) Ensure that the amplifier is the correct voltage for the country it is to be used in.

(ii) Connect your instrument with a high quality shielded instrument cable. You have probably spent considerable money on your amplifier and guitar - don't use poor quality cable it won't do your gear justice.

Please retain your original carton and packaging so in the unlikely event that some time in the future your amplifier should require servicing you will be able to return it to your dealer securely packed.

Care of your Laney amplifier will prolong it's life.....and yours!

Front Panel Controls - SLS/SLS112



NEXUS-SLS and NEXUS-SLS112 have identical front panel layouts and controls.

1 Hi and Lo: Two high impedance (1Meg) inputs. The HI socket is for high output type guitars - this will include most active types. The LO socket is for low signal output type guitars - most passive types with standard pickups. Either socket may be used for the best sound and drive level from your guitar, so experiment! Please note: you can't use the HI and LO sockets at the same time.

Gain Control: This is used to adjust the level of clean or drive sound you require, in conjunction with the Peak Indicator.

● **Peak Indicator:** This shows when tube compression/distortion is occurring. If you want a clean undistorted sound, adjust the gain control to only illuminate the peak light during the very loudest notes. If you want more tube compression and warmth adjust the gain so that the light stays on for more of your playing. As the gain is increased it may be necessary to reduce the Volume control for your desired sound level. At high gain levels, tube clipping/compression will occur. Try the gain at various positions to get your optimum sound. Backing off the volume on your guitar will reduce the compression and distortion characteristics.

● **Compressor Indicator:** Shows when the on board compressor is actively compressing your sound. (Gain Control must be pulled out to operate). At low settings the light will only flash on peaks showing that the amount of compression is only slight. At higher Gain settings the light will illuminate for longer showing more compression is taking place. The amount of compression can also be adjusted via your guitar volume control or playing weight.

2 Shape Switch: A 4 position rotary switch; position one is a bypass or off condition, position 2, 3 and 4 apply three different pre-shaped EQ sounds. An LED adjacent to the switch shows when it is active. When selected, (positions 2,3 or 4) the Shape function may be turned on and off remotely via the remote socket.

Bass Control: This control has a centre off position (12 o'clock) where it has no effect on your sound. Turning the control clockwise increases the level of low frequency bass notes. Turning the control anti-clockwise decreases the level of low frequency bass notes.

Sweep Control: This adjusts the frequency at which the Middle control operates. It ranges from 100Hz to 5kHz with a "low Q".

Middle Control: This control has a centre off position (12 o'clock) where it has no effect on your sound. Turning it clockwise increases the mid frequencies selected by the Sweep control. This can add punch to your sound or extra clarity for on stage performances. Turning anticlockwise decreases the mid frequencies selected by the Sweep control. This can be used to adjust the tonal quality of your guitar sound.

Treble Control: This control has a centre off position (12 o'clock) where it has no effect on your sound. Turning the control clockwise will increase the amount of high frequencies in your sound. Turning anti-clockwise will reduce the amount of high frequencies in your sound.

General EQ Notes: *Start with everything flat then adjust the EQ for your desired sound. Use the controls sparingly and avoid excessive amounts of lift or cut which invariably give poor overall sound.*

3 **Volume Control:** Adjusts the output level of the amplifier. At zero the amplifier is silent. As the control is turned clockwise the maximum power available is increased to its maximum at 9-10. This control should be used in conjunction with the Gain control when distorted or compressed sounds are required.

A high Volume/low Gain setting gives a loud clean sounds.

A low Volume/Hi Gain setting gives compressed/distorted sounds.

The on-board ECC83 tube generates natural, musical, tube tone under all conditions. Pulling out the Volume control will mute the Amplifier (post input buffer). The Tuner/Raw out will still function and signals connected to the Return or Aux inputs will still appear at the speaker output. This could be used to provide a backing track during setup or simply to protect the loudspeaker from the click/pop when first plugging in your guitar. When the Mute is operated, the adjacent LED will flash continuously. This function may also be controlled via the remote socket.

4 **Tip: to operate via the remote FS4-NSL the Volume control must be in the pulled out Mute position.**

Tilt: This control has a centre neutral position. Turning the control clockwise increases the overall mid to high frequencies and decreases the lows thereby giving your sound more presence, which can be useful for cutting through in live band situations.

Turning the control anticlockwise reduces the overall mid to high frequencies and increases the lows making your overall sound rounder. This control operates within the Tube stage so will effect USB right channel record, the headphones, connected speaker and the D.I. output if "Source" switch is set to Output.

Touch: This control has a centre neutral position. Turning the control clockwise makes your sound more open with rounded resonant bass and extended highs. It also gives the amplifier more touch sensitivity. Turning the control anticlockwise makes the sound tighter and faster. This control has only a subtle effect on tonal balance and in general is only something the player can feel as he plays. There are many factors including the speakers/venue and playing style which can determine where this control should be set. This control has no effect on the DI output unless "Source" switch is set to Output but will appear on the USB right channel record, the headphones and the speakers.

Note: *(For operation of this control at least one speaker must be attached to the Master output socket and the impedance switch set to match it).*

Pull Tight: Pull out the touch control to speed up the tube touch response of your sound making it more percussive and a little less warm. A light shows adjacent to this control when operated.

Tip: *spend a little time experimenting with these controls to find the best results.*

5 Tube State Monitor: When you first power up your Nexus, the following will happen:

1: The led will flash at a steady rate - the tube is warming up. This could take up to 30 seconds.

2: The led begins to flash quickly - this indicates the valve is almost ready.

3: The led is continuously on - the amplifier is now ready for use.

Tip: *Trying to use the amp when the led is in state 1 or 2 could result in no audio or degraded quality.*

The time taken for the Nexus to be ready for use depends on the temperature of the valve and ambient temperature. If the amp is turned off and then on relatively quickly, the startup period will be shorter.

6 Interval: This control has a centre off position where it has no effect on your sound and the adjacent light will be extinguished. Turning the control clockwise the light will illuminate and increasing amounts of 5ths are added to your sound. Turning the control anticlockwise will illuminate the light and increasing amounts of Octave down signal will be added to your sound. These features are fully polyphonic with perfect tracking retained at all times.

Tip: *This function can be controlled remotely.*

Focus: This control is used in conjunction with the Interval control. It has a centre position where it has a nominal effect on your sound. Turning the control clockwise will increase the added high frequency harmonics of your sound giving a wide range synth sound. Turning the control anti-clockwise will reduce the higher harmonics subjectively increasing the low end.


Tip: *This control is most noticeable on 5ths. Operation on Octave down is more subtle.*

Space: This control has a centre off position where it has no effect on your sound and the adjacent light will be extinguished. Turning the control anticlockwise will illuminate the light adjacent to the control and add increasing amounts of large hall reverb sound. Turning the control clockwise will illuminate the light adjacent to the control and add increasing amounts of chorus to your sound.

Tip: *This function can be controlled remotely.*


Rear Panel Controls

NEXUS-SLS



Nexus-SLS - Please note additions safety instructions and serial number on bottom panel of unit.

NEXUS-SLS112



- 1 **Universal Power Inlet:** This socket accepts a standard IEC grounded connector supplied with the product. The unit must be earthed under all circumstances! Input voltages from ~100V to ~240V 50-60Hz can be used around the world without need for fuse or voltage changes to the product. Always disconnect the power connector when the amplifier is not in use.
- 2 **Power Switch:** This fully disconnects the mains power to the amplifier. On switching on, the Valve Status LED will begin to flash. Time for the amplifier to be ready for use depends on ambient and tube temperatures.
- 3 **D.I.:** This connector provides a balanced line level feed, primarily used for connecting to a PA sound desk. Also available is a ground lift to be used in the event of hum caused by a ground loop.

There is a source switch allowing the DI output to be sent “PRE” - pre Gain control or “POST” - post EQ and FX, but before the Volume control and “Output” which is post the Volume and all other control functions. This gives the option to send all of the sound including output stage dynamics directly to the mix, avoiding the need for microphones. To allow suitable levels to be sent to the desk there is an associated send Level control.

4 **USB:** There is standard USB 2.0 audio in/out connector which supports the following:

- 1) Ability to simultaneously record the RAW untreated sound to the left channel and the full amplifier sound to the right channel.
- 2) Ability to play back USB stereo information to headphones for monitoring.

Tip: Connect headphone output to the Auxiliary input (5) with a 3.5mm to 6.5mm stereo jack lead allowing simultaneous USB play back.

Tip: This feature will also allow external DSP effects on your DAW to use the RAW signal as a left input then the effected signal sent directly back to the Aux input for mixing with the amp through signal all via USB and without affecting your direct sound.

- 3) Re-Amp Send socket allowing the recorded RAW channel to be sent back to the amplifier input via a standard instrument jack lead for re-processing. **(See Page 17 for further explanation).**

5 **Phones:** A stereo jack socket is provided which can be used for headphones or a stereo feed to a PA system. There is a source switch which can be set to listen to the full amplifier or the stereo return from the USB. A level control is included for comfortable listening.

Tip: Ensure the level is turned down before using to avoid unexpected excessive volume levels.

6 **Tip: When phones are connected, the amplifier output is disabled - this can take a couple of seconds.**

Auxiliary Input: This input allows the connection of backing tracks etc. to be mixed in post the FX loop.

7 It has a level control to aid mixing balance. This input is unaffected by the Mute control but is silenced by the Standby switch.

7 **FX Loop:** This is an insert type loop so all of the signal is passed to the external processor. The mixing of the dry and effect signal must be controlled in your external processor. A switch is provided to allow two nominal levels of loop signal and a bypass option.

8 **Tip: The internal FX operate prior to the external FX loop.**

8 **Tuner/RAW:** The output jack sends an untreated/dry signal to a tuner or DAW system. This output is unaffected by the Mute function.

9 **Remote:** A 5pin DIN connector is provided for connecting the Laney FS4-NSL foot-switch. The functions controlled are: Interval, Space, Mute and Focus.

⑩ **Speaker Connector:** Use the high quality Speakon™ connector to attach your favourite cabinet. If you don't have a male Speakon plug, a standard mono 1/4" jack connector can be used.

Impedance selector switch: Used to select the optimum load impedance matching. It should be set to match the total load of the connected loud speakers. This will ensure optimum operation of the "Touch" control. Incorrect setting will not cause damage or reduced power, but your potential sound quality may be compromised.

Tip: Pay attention to the impedance if multiple cabs are used.

4 Ohms setting: 1x4 Ohms cab or 2x8 Ohm cabs (connected in parallel).

8 Ohms setting: 1x8 Ohms cab or 2x16 Ohm cabs (connected in parallel).

⑪ **Speaker Connector:** as above.

Impedance selector switch: Use to switch between onboard driver or onboard driver plus additional cabinet.

Tip: No damage will occur if switch is set to '**External Connected**' if a cabinet is not connected.

The internal loudspeaker has an 8 Ohm impedance. An additional cabinet connected must be rated at a minimum of 8 Ohms.

Tip: This amplifier is safe to operate without speakers connected. This enables use with only headphones or just as a pre-amplifier within your DAW system.

Please DO NOT use instrument or microphone cables to connect your amplifier and cabinet!

⑫
Nexus-SLS112 only.



⑫ **Horn - On/Off**

This panel and associated controls can have a dramatic effect on the sound. With the horn Full on, the amplifier will give a flat response across the audio bandwidth - ideal in a P.A. situation with a backing track connected to the Aux input.

An electro acoustic bass would also benefit from the horn being on. The resulting sound faithful to the input signal, and rich in harmonics.

A rich/bright sound may not be your thing. No problem, experiment with the horn at full/half power or off altogether.

⑬

Up and running

Before connecting a cabinet, check your settings are correct:

Impedance selector switch: Used to select the optimum load impedance matching. It should be set to match the total speaker connected to the output socket. This ensures optimum operation of “Touch” panel control. Incorrect setting will not cause damage or reduced power but your potential sound quality may be compromised.

Speaker Connectors:


The minimum recommended load is 4 Ohms. Speakon connectors are advised for connecting your cabinets but 1/4” speaker jacks and cable can be used. (Do not use microphone or instrument cables).

Guitar



Nexus-SLS

Using a single cabinet




or daisy-chain multiple cabinets



N410

Nexus-SLS112



Always switch off and disconnect power cord when not in use

Please visit www.Laney.co.uk for other available options.


So what else can I connect?

DI: This connector provides a balanced feed primarily go to a PA mixing console. In the event of hum (caused by a ground loop) lift the ground with the ground Lift switch.

For more information on DI functionality, please see page 11 ③.


Tip: To allow suitable levels to be sent to the console there is an associated send Level control.

Remote: A 5pin DIN connector is provided for connecting a Laney FS4-NSL foot-switch. The functions controlled are Interval, Space, Mute and Shape.



Mixer Desk
or
Powered Cab

Footswitch



Phones, FX processor and Tuner

Phones: Stereo jack is provided which can be used for headphones or a stereo feed to a PA system. There is a source switch which can be set to listen to the full amplifier or the stereo return from the USB. A level control is included for comfortable listening. When the phones are connected, the Speaker Output and Send are muted.


***Tip:** Ensure the level is turned down before using to avoid unexpected excessive volume levels.*

FX Loop: This is an insert type loop so all of the signal is passed to the external processor. The mixing of the dry and effect signal must be controlled in your external processor. A switch is provided to allow two nominal levels of loop signal and a bypass option.

***Tip:** The internal FX operate prior to the external FX loop.*

Tuner/ RAW: The output jack sends an untreated/dry signal to a tuner or DAW system. This output is unaffected by the Mute or Standby functions.

***Tip:** This amplifier is safe to operate without speakers connected. This enables use with only headphones or just as a preamplifier within your DAW system.*



USB interface for PC, Mac or iPad

USB: There is standard USB 2.0 audio I/O connector supporting the following:

1. Ability to simultaneously record the RAW untreated sound to Channel 1 (left) and the full amplifier sound to the channel 2 (right).
2. Ability to play back USB stereo information to headphones for monitoring.

Tip: Can then be linked from the headphone output back into the Auxiliary input with a 3.5mm to 6.5mm stereo jack lead allowing simultaneous USB play back.


Tip: This feature will also allow external DSP effects on your DAW to use the RAW signal as a left input then the effected signal sent directly back to the Aux input for mixing with the amp "through" signal all via USB and without affecting your direct sound.

3. Re-Amp Send socket allowing the recorded RAW channel to be sent back to the amplifier input via a standard instrument jack lead for re-processing.

Record out via USB: To run into iPad or iPad mini connect via a Camera USB adaptor, PC/MAC connects via standard A-B USB cable, for use with the likes of Garage Band®, Audacity®, MixPad Audio Mixer®, Pro Tools and similar. It should be noted that the audio output of an iPad or iPad mini is disengaged and returned via the USB. This can be picked up via a rear panel monitor switch on the amplifier headphones in stereo, or if required, routed into a PA system/powerd cabinets.

Re-Amp Facility: During recording the amplifier processed signal is sent to the right hand channel. The left hand channel carries the guitar signal totally unprocessed. On an iPad using Garage Band if the track is recorded in stereo then copied with one track panned left and the other track panned right, then both raw and processed signals are available independently.

This allows for the re-amplifying of a sound that may have been over processed initially. To re-amp via Garage Band on the iPad, solo the original channel and record a new one with the link in place from the rear re-amp socket and the guitar input. The newly processed signal will now appear on the right channel with the guitar direct signal again on the left. Other effects may be added into the link cable but the guitar original sound will not be recorded. It will instead record to the left channel the sound directly after the effects with no amplifier and the fully processed signal after the amplifier and effects on the right.



The Nexus-SLS/SLS112 uses a specially selected and tested high voltage pre-amp tube which should give you years of trouble free service. However like all tube amps; it is important to treat it with a certain amount of care. Use the following steps as a guide for how to take care of your amplifier:

- Take care when moving the amplifier. Tubes are fragile glass components, they can easily be damaged if thrown in and out of a van.
- Allow the amplifier to warm up to room temperature before switching it on: the sudden thermal shock can crack a cold glass tube enclosure, plus any moisture is bad news around high voltage electronics.
- After playing, allow the amplifier to cool down before moving. Hot tubes are more fragile than cool ones.

A tubes life expectancy is based upon a number of factors which include operating temperature, how hard and how often it is played, vibration due to travel, etc. Tubes should be changed in your amplifier if you notice any deterioration in your amplifiers sound or performance. Otherwise, they need not be changed at any regular interval. Problematic tubes can cause crackly noises, hiss, excessive distortion, microphony and low output power.

Important: The user should not attempt to service this product!

Method for replacing tube V1 (by Qualified Service Engineers only).


Firstly switch off and unplug the amplifier from the mains supply. Remove the top cover. The tube is protected with a screen can; to remove, push down and twist the can anti clockwise and then pull up. The tube can now be gently pulled out. Take care when inserting the new tube to make sure all pins are correctly aligned. Replace the top cover before connecting to the mains supply.

Important: ONLY fit the recommended tube PN: 005550

Failure to do so could result in malfunction/mis-operation of your Nexus-SLS/SLS-112.

DO NOT operate with the top cover removed.

Block Diagram



Specifications

	Nexus-SLS	NexuSL-S112
Operating Voltage Range:	~100V to ~240V 50-60Hz.	~100V to ~240V 50-60Hz.
Average power consumption:	200W (Measured at 1/8th continuous output power)	200W (Measured at 1/8th continuous output power)
Power Output:	1x500W into 4 Ohms / 1x250W into 8 Ohms	1x500W into 4 Ohms / 1x250W into 8 Ohms
Load Impedance:	1x4 Ohms, 2x8 Ohms	1x8 Ohms, 2x16 Ohms
Output Voltage:	~70V Peak	~70V Peak
Input Impedance:	1MegOhm & 100pF	1MegOhm & 100pF
Input Overload:	Hi Input =>~20V Lo Input >~3V	Hi Input =>~20V Lo Input >~3V
Input Sensitivity:	Lo Input/ EQ Flat/Gain Max/Volume Max =~15mV	Lo Input/ EQ Flat/Gain Max/Volume Max =~15mV
FX Loop Sensitivity:	0dBu/-10dBu (Nominal dependant on control settings)	0dBu/-10dBu (Nominal dependant on control settings)
USB:	44.1kHz Standard Slave CODEC (PC/MAC/iPad compatible)	44.1kHz Standard Slave CODEC (PC/MAC/iPad compatible)
Unit Dimensions:	H70mm, W318mm, D235mm	H461mm, W435mm, D400mm
Carton Dimensions:	H150mm, W442mm, D299mm	H537mm, W503mm, D468mm
Weight:	4.5Kg (Unit) 5Kg (Packed)	19.5Kg (Unit) 21Kg (Packed)
Construction/ features:	Sturdy steel chassis	Lightweight, plywood construction
	Ergonomic and stylish handle design	TUFF STUFF / black finish
		Rugged corner handles
		Unique Tilt mechanism
Drivers:	N/A	Lightweight 12" Neodymium driver
	N/A	1" Exit Compression Driver with switchable ON/OFF and HI/LO

nexus
STUDIO LIVE

In the interest of continued development, Laney reserves the right to amend product specification without prior notification.

Legal

FCC Compliancy Statement



This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference
- 2) This device must accept any interference received, that may cause undesired operation.

Warning: Changes or modification to the equipment not approved by Laney can void the user's authority to use the equipment.

Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



This product conforms to the requirements of the following European Regulations, Directives & Rules:
CE Mark (93/68/EEC), Low Voltage (2014/35/EU), EMC (2014/30/EU),
RoHS (EU2011/65/EU), ErP (2009/125/EU).



In order to reduce environmental damage, at the end of its useful life, this product must not be disposed of along with normal household waste to landfill sites. It must be taken to an approved recycling centre according to the recommendations of the WEEE (Waste Electrical and Electronic Equipment) directive applicable in your country.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

Mac, Mac OS & iPad are trademarks of Apple Inc., registered in the U.S. and other countries.

Audacity is a trademark of Dominic Mazzoni.

MixPad Audio Mixer is a trademark of NCH Software, Inc.

Pro Tools is a trademark registered in the United States by Avid Technology, Inc.

Speakon is a trademark of Neutrik®AG.

(USB2.0 is compatible with Windows XP ® operating system, Windows 7 ® operating system & Windows 8 ® operating system. Also compatible with Mac ® & iPad ® 1-3 via camera USB adaptor, iPad ® & iPad Mini ® via Lightning-USB camera adaptor cable.)



Model number:
Serial number:
Place of purchase:
Date of purchase:
Please complete for future reference.



www.laney.co.uk

Issue 2.00