


JUPITER[®]
World Class Quality



WOODWIND INSTRUMENTS
Parts Reference Guide

- *D Prodigy Flute*
JFL-313

05

• *D Prodigy Flute*
JFL-313

• *D Prodigy Flute*
JFL-313

Dia. Ref.	Part No	Description
1	51-U001	Bow headjoint ass'y
2-3	51-N019	Straight headjoint ass'y
1-7	SFLH-313S	Curved headjoint ass'y
3	51-N003	Lip plate
4	51-N009	Flute head stopper screw
5	51-C101	Flute head stopper cork
6	51-N601	Flute head stopper nut
7	51-N403	Flute head crown
9	51-D004	Barrel joint
10	51-D0041	Body ass'y w/out keys
10	51-D0026	Body ass'y w/out keys (prior to ser. # L00001)
11	51-D405	Body ring
11	51-D410	Body ring (prior to ser. #J00001)
12	51-W0031	Key post ass'y
13	51-W0032	Key post ass'y
14	51-W0022	Key post ass'y
15	51-W0025	Key post ass'y
19	51-K014	C key
19	51-K0041	C key (prior to ser. # L00001)
20	51-K0057	Bb thumb lever
21	51-K0049	B key
22	51-K0140	Bb key
22	51-K0065	Bb key (prior to ser. # L00001)
23	51-K0190	A key
23	51-K0075	A key (prior to ser. # L00001)
25	51-K0191	G key
25	51-K0076	G key (prior to ser. # L00001)
26	51-K0144	G# key
26	51-K0051	G# key (prior to ser. # L00001)
27	51-K0080	Bb lever
28	51-K0067	F# key
29	51-K0192	F key
29	51-K0077	F key (prior to ser. # L00001)
30	51-K0193	E key
30	51-K0078	E key (prior to ser. # L00001)
31	51-K0134	Joint key
31	51-K0061	Joint key (prior to ser. #K00001)
32	51-K0135	D key
32	51-K0079	D key (prior to ser. # L00001)
35	51-K0194	D# key
35	51-K0081	D# key (prior to ser. # L00001)
41	51-P006	Pad set
42	51-A301	Pad metal washer
43	51-C202	Pad screw
16-31*	51-A5002	Knock pin
16-31*	51-A502	Knock pin (prior to ser. #H00001)
16-32*	51-C007	Shaft set
16-32*	51-C205	Pivot screw
16-35*	51-S003	Needle spring set
19-35*	51-C006	Rod screw set
20-21*	51-S101	Flat spring
20-21*	51-C204	Flat spring screw
22-31*	51-C201	Adjusting screw

