

Sequencer Calibration

You need to adjust the trimmers R39 and R42 for maximum output voltage.

Set all step level potentiometers all way clockwise (to max position) and flip the level switch to 5V.

Now, connect the multimeter to the output CV jack and observe the voltage. Adjust the R39 to read 5V. Flip the switch to 3V and adjust the R42 to read 3V on the output.

Calibration done!