

CANVAS EXPRESSION



CONGRATS ON YOUR NEW EXPRESSION PEDAL

You've just unlocked an all new way to create with programmable control over expression, switch, and CV signals. Of course you can use this to ramp up time on your delay pedal, but with MIDI CC and PC messages, and deep configuration control through the Canvas web app (canvasexp.walrusaudio.io), you have near endless possibilities to...you guessed it...express yourself.

GETTING STARTED

Power - 9 V Center Neg. 300mA.
We recommend using an isolated power supply.

Tucked under the heel of the pedal is the Expression user interface with two buttons and four parameter LEDs above them. These LEDs will tell you which parameter you're currently changing.

TO EDIT A PARAMETER:

1. Select which Jack you will be editing by pressing both buttons simultaneously. The Jack Edit Selection LEDs will toggle between A and B.
2. Press the right or left buttons to select the desired parameter. As you move through the parameters, the current setting for each is displayed with the value LEDs.
3. To increase the value of the selected parameter, press and hold the left button while clicking the right button.
4. To decrease the value, press and hold the right button while clicking the left button.

Jacks A and B can each be configured to send Expression Out, Switch Out, or CV Out.

MIDI can be sent or received from the dedicated 1/8" MIDI TRS Type A connectors on the right side of the device or sent over USB when connected to a computer.

All MIDI setup is handled through the Canvas Expression web app at canvasexp.walrusaudio.io



Scan the QR code to view the full manual, register your pedal, watch videos, and more.