Before using this unit, carefully read "USING THE UNIT SAFELY" and "IMPORTANT NOTES". After reading, keep the document(s) where it will be available for immediate reference.

Installation

The NEQ-K/NEQ-H are anti-vibration boards exclusively for use with the VQD series.

Refer to "Setting examples" when using this product.

NEQ-K	For kick pedals only	Front (sticker):  Rear: 
NEQ-H	For hi-hat control pedals only	Front (sticker):  Rear: 

To obtain maximum insulation of vibration, please note the following points.

- Be sure to set up the kick pedal on the NEQ-K and the hi-hat control pedal on the NEQ-H.
- Place on a flat and stable floor so that the rubber feet contact the floor evenly.
- When the unit is placed on thick-pile carpeting, the rubber feet may sink into the pile, reducing the noise insulating effect.
- Place the kick pedal or hi-hat control pedal on the center of the NEQ-K/NEQ-H, making sure that the device does not extend beyond the edge of the NEQ-K/NEQ-H.

Setting examples

NEQ-K

Kick pad

Place the unit as shown in the illustration.

* For details, refer to the owner's manual of the kick pad.

Use the anchor bolts to secure the kick pedal as necessary.

You can peel off the "for Kick" sticker (front) once you've set up the product.



Using double kick pedals

To effectively reduce vibrations, use the NEQ-K with the other kick pedal as well.

NEQ-H

Hi-hat control pedal

Place the unit as shown in the illustration.

Use the anchor bolts to secure the unit as necessary.

You can peel off the "for HiHat" sticker (front) once you've set up the product.



USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠WARNING and ⚠CAUTION Notices

⚠WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

⚠	The ⚠ symbol alerts the user to important instructions or warnings.The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
🚫	The 🚫 symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
🔌	The 🔵 symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

Do not use for other purposes

This product is a vibration-reducing accessory only for use with V-Drums.

Do not disassemble or modify by yourself

Do not carry out anything unless you are instructed to do so in the owner's manual. Otherwise, you risk causing malfunction.

Do not repair or replace parts by yourself

Be sure to contact your dealer, a Roland service center, or an official Roland dealer.

For a list of Roland service centers and official Roland dealers, refer to the Roland website.

Do not use or store in the following types of locations

- Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
- Damp (e.g., baths, washrooms, on wet floors); or are
- Exposed to steam or smoke; or are
- Subject to salt exposure; or are
- Exposed to rain; or are
- Dusty or sandy; or are
- Subject to high levels of vibration and shakiness; or are
- Placed in a poorly ventilated location.

Do not place in an unstable location

Otherwise, you risk injury as the result of the unit toppling over or dropping down.

Be cautious to protect children from injury

Always make sure that an adult is on hand to provide supervision and guidance when using the unit in places where children are present, or when a child will be using the unit.

⚠ WARNING

Do not drop or subject to strong impact

Otherwise, you risk causing damage or malfunction.

⚠ CAUTION

Keep small items out of the reach of children

To prevent accidental ingestion of the parts listed below, always keep them out of the reach of small children.

- Removable Parts
  Sticker

IMPORTANT NOTES

Placement

- Depending on the material and temperature of the surface on which you place the unit, its rubber feet may discolor or mar the surface.
- Do not place containers or anything else containing liquid on top of this unit. Also, whenever any liquid has been spilled on the surface of this unit, be sure to promptly wipe it away using a soft, dry cloth.

Maintenance

- Never use benzine, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Additional Precautions

- The carbon included in this product may blacken nearby items, but this can be removed with a pencil eraser.
- Additives in the surface of the rubber may whiten with the passage of time, but this does not affect the performance or functionality of the product.
- Do not stand on top of this product, or place any instrument other than V-Drums on it; doing so may cause deformation or damage.
- This instrument is designed to minimize the extraneous sounds produced when it's played. However, since sound vibrations can be transmitted through floors and walls to a greater degree than expected, take care not to allow these sounds to become a nuisance others nearby.
- When disposing of the packing carton or cushioning material in which this unit was packed, you must observe the waste disposal regulations that apply to your locality.
- This document explains the specifications of the product at the time that the document was issued. For the latest information, refer to the Roland website.

Intellectual property right

- Roland and V-Drums are either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.

* 5 1 0 0 0 8 9 8 0 1 - 0 1 *

© 2024 Roland Corporation