



www.xviveaudio.com

V11 Noise Gate

Precautions

PLEASE READ CAREFULLY BEFORE PROCEEDING

Power supply

Please connect the designated AC adapter to an AC outlet of the correct voltage. Please be sure to use only an AC adapter which supplies 18V (+10%) DC, center minus. The maximum working voltage shall not exceed 24V, otherwise may be dangerous equipment damage, fire, or other problems. Unplug the AC power adapter when not using or during electrical storms.

Connections

Always turn off the power of this and all other equipment before connecting or disconnecting, this will prevent malfunction and/or damage to other devices. Also make sure to disconnect all connection cables and the power cord before moving this unit.

Handling

Do not apply excessive force to the switches or controls. Do not let paper, metallic, or other objects into this unit. Take care not to drop the unit and do not subject it to shock or excessive pressure.

Cleaning

Clean only with a soft, dry cloth. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint thinners, wax, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Location



To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- .Direct sunlight
- .Heat sources
- .Magnetic fields
- .Extreme temperature or humidity
- .Excessive dusty or dirty location
- .High humidity or moisture
- .Strong vibration or shocks

Main features

- .100% attenuation when gated
- .Wide range threshold control
- .utilizes ultra-high speed circuitry to completely eliminate non-musical sounds from your signal path
- . True bypass

Panel instruction



1.TRUE BYPASS Footswitch:

Push down the footswitch to switch between effects and bypass status

2.DC IN Power Jack:

For power supply, use a 9V DC regulated AC adapter(plug polarity is positive on the barrel and negative in the center).

3.INPUT Jack:

1/4" mono audio jack, for connecting guitar.

4.OUTPUT Jack:

1/4" mono audio jack, outputs the signal.

5.THRESHOLD Knob:

Is the most important control on the Gatekeeper pedal. This knob controls how much signal is needed in order to open the gate. The hotter the signal you put into the Gatekeeper, the lower the THRESHOLD knob should set. The best way to set the THRESHOLD knob on the Gatekeeper is to start with the knob turned all the way counter-clockwise and then slowly move it in the clockwise direction until the gate remains closed when you are not playing, but opens up Immediately when you play a note. The THRESHOLD knob should be set somewhere in a region where the noise in your system is below the level needed to open the gate and the sound of your instrument is above the level needed to open the gate. If the THRESHOLD knob is set completely counter-clockwise, the gate will not open and your sound will remain muted.

6.The MUTE LED:

Turns on when the signal has fallen below the threshold needed to keep the gate open, the Mute LED will keep on when the pedal on true bypass mode.

7.The Effect LED:

Indicate the effects is on or off

Specifications

Input: 1/4" monaural jack (impedance: 470k ohms)
Output: 1/4" monaural jack(impedance: 150R ohms)
Power Requirements: AC adapter 9V DC (center minus plug)
Current Draw: 20 MA
Dimensions:46 (W) *94 (D) *50 (H) mm
Accessories: Owner's manual



www.xviveaudio.com

Disclaimer: Any specification's update won't be amended in this manual

尺寸：100*150MM

材质：80g书纸

正反面印